

Neles™ positioner

Series NE

Installation, maintenance and
operating instructions




Table of Contents

INTRODUCTION	3	SPLIT-RANGE ADJUSTMENT	11
General view	3	MAINTENANCE	11
Principle of operation	3	Supply air filter	11
Marking of positioner	3	Pilot valve	11
Technical specifications	4	Replacement of the diaphragms	12
Recycling and disposal of a rejected positioner	4	Force coil-nozzle assembly	12
Safety precautions	4	Changing the restriction assembly	12
MOUNTING ON THE NELES ACTUATOR	5	TROUBLESHOOTING	12
General	5	Electrical defects	12
Installing positioner NE700/S1 on		Mechanical defects	13
Neles actuators with VDI/VDE 3845 mounting face	5	OPTIONS	13
NE_700/700 positioner/limit switch combination (Obsolete since 2013)	5	NE700/R dust-proof construction (IP65)	13
Piping of supply air	5	NE700/A with pressure gauges	13
Instrument air supply	8	TOOLS	13
Electric connections	8	ORDERING SPARE PARTS	13
INPUT SIGNAL AND DIRECTIONS OF OPERATION	8	DRAWINGS AND PARTS LISTS	14
Changeover piece	8	Exploded view and parts list	14
Cam plate	8	Mounting parts for B1C6-502 and B1J8-322 actuators (S1)	16
PRELIMINARY ACTIONS FOR THE ADJUSTMENT	9	Mounting parts for Quadra-Powr® actuators (S1)	17
Position of the changeover piece	9	Mounting parts for B1C6-20 and B1J8-20 actuators (S2)	18
Pilot valve	9	Mounting parts for B1C25-502 and B1J25-322 actuators (S2)	19
Setting the internal feed-back spring	9	TYPE CODE	20
Position of the cam plate	9		
BASIC ADJUSTMENT	10		
a₀ ADJUSTMENT	10		

READ THESE INSTRUCTIONS FIRST!

These instructions provide information about safe handling and operation of the positioner. If you require additional assistance, please contact the manufacturer or manufacturer's representative. Addresses and phone numbers are printed on the back cover.

SAVE THESE INSTRUCTIONS!

Subject to change without notice.

All trademarks are property of their respective owners.

1 INTRODUCTION

1.1 General view

Neles™ NE700 electro-pneumatic positioner is used for positioning double or single acting actuator.

1.2 Principle of operation

Operation is based on the torque balance. Force coil (152) located in the field of the permanent magnet (168) creates a torque proportional to the signal current on the balance beam (164).

The feed-back spring (41) causes a counter-torque proportional to the actuator position; this position is transmitted via the actuator shaft, the coupling (52), the feed-back shaft (26), the cam plate (29) and the lever (33) as a relative displacement to the lower end of the feed-back spring (41).

The nozzle (166) senses the torque balance on the beam (164). When the input signal increases, the balance beam (164) approaches the nozzle (166) and the nozzle pressure rises. This causes the diaphragm piston (8), the beam (5) and the spool (44.2) to move downward. The pilot valve (44) distributes supply air (S) to the upper side of the actuator piston via channel C2, and from the lower side via channel C1 through the pilot valve (44) to the exhaust port. The actuator piston moves until the balance beam is in equilibrium. At this point the actuator is exactly in the position required by the input signal.

The spring (40) causes a negative feed-back between the first amplification stage (nozzle 166 and restriction 24) and the second (pilot valve assembly 44). By changing the lower fastening point for the spring (40) on the balance beam (164), the dynamics of the positioner can be adapted to suit the actuator size.

The zero adjustment (61) is mechanical and the range adjustment (35.6) is electrical.

The differential diaphragms effectively offset the effect of fluctuations in the supply pressure.




Fig. 1 Schematic diagram

Parts list for Figure 1:

Item	Part
5	Beam
8	Diaphragm piston
24	Restriction
26	Feed-back shaft
29	Camplate
33	Lever
35.6	Range adjustment
40	Internal feed-back spring
41	Feed-back spring
44.1	Pilot valve body
44.2	Pilot valve spool
46	Changeover piece
52	Coupling
61	Zero adjustment
152	Force coil
164	Balance beam
166	Nozzle
168	Permanent magnet

1.3 Marking of positioner

The positioner has an adhesive ID plate, see Fig. 2.

The ID plate contains the following information (from top to bottom):

- Full type designation of the positioner
- Input signal
- Input resistance
- Max. supply pressure
- Enclosure class
- Ambient temperature range
- Manufacturing series number




Fig. 2 Example of ID plate

An additional plate, Fig. 3, has markings:

- Filter regulator (-K)
- Temperature range
- Conduit entry (-L, -I or -NJ)




Fig. 3 Example of additional plate

1.4 Technical specifications

Input signal (direct current)	4–20 mA, 0–20 mA
Split ranges	4–12 mA 12–20 mA
Input resistance	max. 190 Ω
Turning angle of feed-back shaft	max. 90°
Relation between turning angle and signal (standard model)	linear
Supply pressure ps	1.4–8 bar (21–115 psi)
Effect of supply pressure	< 0.2 % / 0.1 bar (< 0.14 % / 1 psi)
Ambient temperature (standard model)	-25° to +85 °C (-13° to +185 °F)
Effect of temperature	< 0.05 % / °C (< 0.025 % / °F)
Performance with 12 % friction loaded double-acting piston actuator	
-dead band	< 0.3 %
- hysteresis	< 0.7 %
-linearity	< 2 %
Effect of vibration (1.5 g, 5-100 Hz)< 1 %	
Enclosure class	IP 54
Weight	approx. 2.2 kg (4.8 lb)
Construction materials:	
-case	anodized Al alloy
-cover	polycarbonate
-internal parts	stainless steel, aluminium alloy and stainless spring steel
- diaphragms and seals	nitrile rubber (standard model)

Table 1 Pilot valve alternatives

Positioner type	Actuator stroke volume dm ³ (litres)	Air consumption nm ³ /h / scfm *)	Max. delivery nm ³ /h / scfm *)
NE724	1.0–8.0	0.9 / 0.5	12 / 7
NE726	8.0–30.0	1.2 / 0.7	18 / 10.4
NE727	> 30	2.1 / 1.2	32 / 18.6

*) supply pressure 4 bar / 60 psi

1.5 Recycling and disposal of a rejected positioner

Most positioner parts can be recycled if sorted according to material. Most parts have material marking. A material list is supplied with the positioner. In addition, separate recycling and disposal instructions are available from the manufacturer. A positioner can also be returned to the manufacturer for recycling and disposal against a fee.

1.6 Safety precautions

CAUTION:
Do not exceed the positioner performance limitations!
Exceeding the limitations marked on the positioner may cause damage to the positioner, actuator and valve.
Damage or personal injury may result.

CAUTION:
Do not dismantle a pressurized positioner!
Dismantling a pressurized positioner will result in uncontrolled pressure release. Always isolate the relevant part of the pipeline, release the pressure from the positioner and the piping.
Failure to do this may result in damage or personal injury.

CAUTION:
Beware of the parts with live voltage!
A voltage, which is normally not dangerous, is supplied to the positioner. Avoid touching live parts and bare wires and short circuiting live parts and the housing.

CAUTION:
Beware of the moving parts when positioner is operated!

2 MOUNTING ON THE NELES ACTUATOR

2.1 General

When the positioner is supplied together with the valve and actuator, the tubes are mounted and the positioner adjusted in accordance with the customer's specifications.

When the positioner is ordered separately, the mounting parts for the assembly must be ordered at the same time.

Example order: Positioner alone (BC12)-Z-NE724.

The positioner is equipped with VDI/VDE 3845 (S1) mounting face. This mounting face requires a shaft with the H coupling.

Old Neles style mounting face code S2 is no more available.

For mounting parts for Neles actuators, see Sections 13.2 - 13.3.

2.2 Installing positioner NE700/S1 on Neles actuators with VDI/VDE 3845 mounting face

1. The actuator piston must be in the up position (in spring-return actuators as determined by the spring).
2. Install the pointer (only B_U) parallel with the valve closure member and fasten the draught piece (2) with a screw (29) to the pointer cover (B_U) or to the coupling (QP), as shown in Fig. 5. Secure the draught piece fastening screw with a sealant (e.g. Loctite) and tighten it properly.
3. Fasten the mounting bracket (1) to the positioner.
4. Fasten the mounting bracket (1) to the actuator.




Fig. 4 Installing on a Neles actuator (S1)

2.3 NE_700/700 positioner/limit switch combination (Obsolete since 2013)

The bottom of the limit switch acts also as the cover for the positioner. Remove the limit switch before the adjustment of the positioner.

1. Loosen the cover screws. Note the position of the shaft relative to the positioner when removing the limit switch.
2. When the adjustment of the positioner is done, operate the actuator until the valve is in the closed or open position.
3. Note the position of the actuator and valve when mounting the limit switch on the actuator. Make sure that the position of the shaft is unchanged relative to the positioner.
4. Place the limit switch on the positioner so that the shafts are correctly engaged.
5. Fasten the cover screws.
6. Check the adjustment of the limit switch. See the instruction manual of the limit switch for details.

2.4 Piping of supply air

Table 2 provides the recommended pilot valve and tube sizes in accordance with the actuator sizes. Tube sizes are minimum values allowed.

Connect air supply to S (1/4 NPT).

Connect C1 and C2 (1/4 NPT) to the actuator according to Fig. 6.

See also Chapter 3.

NOTE:

A single action connection alone is permitted for positioners mounted on the spring actuator!

Place a plug in connection C1 or C2. See Figure 6.

For pipe threads are liquid sealants, e.g. Loctite, recommended.

NOTE:

Excessive sealant may cause faulty operation of the positioner.


Sealing tape is not recommended.

Ensure the cleanliness of the air piping.

Table 2 Piping and operating times

Actuator		NPT	Piping						Operating time / stroke (s) pilot valve			
B1C	Stroke vol. dm ³ /in ³		Plastic/Cu/SS (mm)			Plastic/Cu/SS (")			ø4LC	ø4	ø6	ø6 HC
			6/4	10/8	12/10	1/4	3/8	1/2				
6	0.3/20	1/4	x			x			1	1		
9	0.6/37	1/4	x			x			1.5	1.5		
11	1.1/67	3/8	x			x			2	2		
13	2.3/140	3/8		x			x			4		
17	4.3/262	1/2		x			x			7	(6)	
20	5.4/330			x			x			8.5	(5.5)	
25	10.5/640	1/2		x	(x)		x	(x)			10	(8.5)
32	21/1282	3/4		x	(x)		x	(x)			17	(16)
40	43/2624	3/4			x		(x)	x			(33)	31
50	84/5130	1			x		(x)	x			(60)	57
502	195/11900	1			x			x				
B1J B1JA	Stroke vol. dm ³ /in ³	NPT	6/4	10/8	12/10	1/4	3/8	1/2	ø4LC	ø4	ø6	ø6 HC
6	0.47 / 28.7	1/4	x			x			1	1		
8	0.9/55	3/8	x			x			1.5/3	1.5/3		
10	1.8/111			x			x			2.5/5.5		
12	3.6/225	1/2		x			x			4.5/11	(3.5/6)	
16	6.7 / 415			x			x			8/18	(4.5/11)	
20	13/795	3/4		x	(x)		x	(x)			8.5/21	(7.5/19)
25	27 / 1642			x	(x)		x	(x)			17/38	(15/33)
32	53 / 3231	1			x		(x)	x			(33/74)	30/64
322	106 / 6480				x			x				60/130
QP	Stroke vol. dm ³ /in ³	NPT	6/4	10/8	12/10	1/4	3/8	1/2	ø4LC	ø4	ø6	ø6 HC
1C	0.62/38	3/8	x			x			1.5/2	1.5/2	-	-
2C	1.08/66	3/8	x			x			2/3.5	2/3.5	-	-
3C	2.18/133	3/8		x			x		-	3/5	2/3	-
4C	4.34/265	3/8		x			x		-	6/10	4/6	-
5C	8.7/531	3/8		x			x		-	-	7/10	
6C	17.5/1068	3/4			x			x	-		12/18	10/15

Times in parenthesis are achieved by changing pilot valve alone or pilot valve and tube size.



Operating times for spring return actuators B1J/B1JA and QP:
against the spring / direction of the spring

Actuator without valve:

$p_s = 4-5 \text{ bar} / 58-72 \text{ psi}$

Step of input signal:

$p_i = 0-100 \% \text{ and } 100-0 \%$




Fig. 5 Positioner actions

NOTE: In positioner NE727 the changeover piece can be used in position R only.

2.5 Instrument air supply

CAUTION:

Do not exceed the permitted actuator supply air pressure!

The supply air must be clean, dry and oil-free instrument air, e.g. according to standard ISA S7.3-81. Supply pressure is 1.4–8 bar (20–115 psi).

2.6 Electric connections

The input signal cable is lead through a PG11 cable gland to the housing. Connect the conductors to the terminal on the terminal card, plus (+) and minus (-) accordingly. See Fig. 7. The wiring schematic is shown in Fig. 8.

NOTE:

The wires should not be led through the operational area of the feed-back lever (33) and feed-back spring (41).




Fig. 6 Terminal card




Fig. 7 Wiring schematic

3 INPUT SIGNAL AND DIRECTIONS OF OPERATION

Figure 6 assists in choosing the right segment for the cam plate (29) and position for the changeover piece (46).

3.1 Changeover piece

CAUTION:

Do not dismantle a pressurized positioner!

The function of connection C1 and C2 can be altered by turning the changeover piece (46). The diagram D (or R) shown on the protective plate (48) functions when the symbol D (or R) is visible in the lower lefthand corner of the changeover piece. D = direct, R = reverse.

External changes in the tubes are not needed. Positioner NE727 is an exception (DIA6HC pilot valve). Then the changeover piece must always be in position R and the external tubes mounted in accordance with Fig. 6.

3.2 Cam plate

The figures marked on the cam plate (29) are the signal ranges expressed as percentages, for example 0–100 corresponds to 4–20 mA, or 50–100 to 12–20 mA. See Fig. 9.

The arrows on the cam plate show the direction it must turn when the input signal is rising in the cam segment in question.

The non-rising segments between the rising segments are roughly 15°–20°.




Fig. 8 Input signal ranges

4 PRELIMINARY ACTIONS FOR THE ADJUSTMENT

Set the valve's open and closed limits with the actuator limiter screws; see the valve instruction manual. The changeover piece (46), the cam (29) and the internal feed-back spring (40) must be in correct positions. Check the pilot valve size from Table 2.

The adjustment must always be carried out when the supply pressure has been changed.

Please note that operating of the valve is required during the adjustment.

4.1 Position of the changeover piece

CAUTION:

Do not dismantle a pressurized positioner!

Choose the position of the changeover piece, D or R, from Fig. 6 in accordance with the function desired.

Turn the changeover piece (46) when necessary.

Loosen the nuts (49) and remove the protective plate (48). Pull out the changeover piece (46). Check the O-rings (47, 2 pcs.) and apply silicone grease lightly if needed. Place the changeover piece (46) and the protective plate (48) in the case. Tighten the nuts (49) evenly, one after the other.

NOTE:

Check that the changeover piece is mounted correctly: Symbol D or R is visible in the lower left hand corner.




Fig. 9 Mounting the changeover piece

4.2 Pilot valve

Removal of the pilot valve is unnecessary when the changeover piece is turned around. For instructions of removal, see Section 8.2.

4.3 Setting the internal feed-back spring

Select the position for the lower end of the spring (40) from Table 3 in accordance with the actuator size. The spring setting must be made before the zero adjustment of the positioner, as it affects the adjustment.

The amplification of the positioner increases as the spring (40) is moved from position 'a' to position 'e'.

If in the field the valve overshoots, the spring (40) can be moved to the 'a' direction. If the valve goes into position too slowly the spring can be moved to the 'e' direction respectively.

In sticker inside the cover (2) has also been shown the position for the lower end of the spring (40) in accordance with the actuator size.




Fig. 10 Setting the internal feed-back spring

Table 3 Setting the internal feed-back spring

Spring (40) setting	Actuator size	Cylinder volume dm ³
a	B1C 6, 8, B1J 6 QP 1	<0,5
b	B1C 9, 11, 12; B1J 8 QP 2 (QP 1 *)	0,5...1
c	B1C 13, 16; B1J 10, 12 QP 3 (QP 2 *)	1...4
d	B1C 17, 20, 25; B1J 16 QP 4, QP 5 (BJ 8 *)	4...11
e	B1C 32, 40; B1J 20, 25 B1C 50, 502; B1J 32, 322	11...50

*) NE729S positioner, (Obsolete since 2013).

4.4 Position of the cam plate

Choose the side, A or B, and the rising segment of the cam plate from Fig. 6 in accordance with the function desired.

Move the actuator piston to the end where the input signal has its lower value. Shut off the supply pressure or move the pilot spool by deflecting the balance beam (164) gently so that the piston strokes to the desired limit. The input signal should be zero or at the lower limit.

NOTE:

Don't move the pilot spool by deflecting the beam (5).

The double diaphragm keeps the beam steadfast in the position.

Loosen the screw (57), remove the indicator (32), loosen the screw (31) and the locking wheel (30). Turn the cam plate (29) to the desired side.

In case of α_0 adjustment, proceed acc. to Sections 6.1 and 6.2.

Place the roller so that its contact point is 1 mm from the beginning of the rising segment. Then tighten the locking wheel (30) and the screw (31).

5 BASIC ADJUSTMENT

Basic adjustment is made to rotary and butterfly valves.

Please note the procedures in Chapter 4 before the adjustment.

1. Switch on the supply pressure (S) and the input signal (+/-).
Note the correct polarity.
2. Set the input signal at the closed limit of the valve so that it is 2 % i.e. 0.3 mA higher or lower than the limit value, e.g. $4 + 0.3 = 4.3$ mA or $20 - 0.3 = 19.7$ mA. Turn the zero adjustment nut (61) with a screwdriver or fingers so that the actuator comes slowly to the closed limit. The valve should open slightly with a 4 % change in signal, that is 0.6 mA, e.g. $4 + 0.6 = 4.6$ mA or $20 - 0.6 = 19.4$ mA. See Figures 12 and 13.
3. Set the input signal to the other limit value. The valve should be entirely open at 100 %, i.e. 20 mA or 0 %, i.e. 4 mA. The valve should start to operate to closed direction at 98 %, i.e. 19.7 mA or 4.3 mA.
The range, i.e. turning angle, increases by turning the range adjustment potentiometer (35.6) counterclockwise and decreases by turning clockwise.
4. The zero and range adjustments affect each other, so stages 2 and 3 must be repeated a few times.
5. Screw on the pointer (32) into place so that the yellow line is in the direction of the valve closing member. Tighten the screw (57).




Fig. 11 Basic and α_0 adjustments




Fig. 12 Zero and range adjustments

6 α_0 ADJUSTMENT

α_0 adjustment is made to segment and ball valves. This adjustment takes into account the "dead angle" α_0 of the ball valve. The entire signal range is then used for effective valve opening $90^\circ - \alpha_0$, see Figure 14.




Fig. 13 Zero and range adjustments

The same adjustment method can be applied to butterfly valves in papermills for pulp flow control to avoid the dewatering of the pulp near the closed position of the disc.

Table 4 shows the shift on the circumference of the cam equal to the "dead angle" of the valve, Figure 15, in various cam segments (C, E, D). Please note the procedures in Chapter 4 before the adjustment.




Fig. 14 Shift on circumference of cam equal to dead angle

1. Mark the shift in question on the edge of the cam, Fig. 15 and Table 4. Dimensions do not have to be measured if the dead angle can be reliably noticed from position of the closing member.
2. Lock the cam so that the roller touches the edge of the cam plate at the mark. Tighten the locking wheel (30) and the screw (31).
3. Switch on the supply pressure (S) and the input signal (+/-). Note the correct polarity.

Table 4 Dead angle in degrees

Valve size		Valve series							
		MBV QMBV 1)	MBV QMBV 2)	D 3)	T5, QT5	QXT5	T25, QT25	QXT25	R, QR
mm	mm	Dead angle in degrees							
25	1	12.5	-	-	23.0	17.5	-	-	14
40	1 1/2	11.0	-	-	22.0	11.0	-	-	11
50	2	9.0	8.0	12.0	22.0	11.0	16.0	7.0	15
65	2 1/2	8.0	-	-	-	-	-	-	11
80	3	9.0	7.0	11.0	16.0	7.0	15.0	8.0	8
100	4	9.0	7.0	11.0	15.0	7.5	14.5	8.0	7
125	5	11.0	-	-	-	-	11.0	6.0	7
150	6	9.0	7.0	10.5	14.5	8.0	12.0		7
200	8	8.0	6.5	7.5	11.0	6.0	8.5		6
250	10	8.0	6.5	7.0	12.0		8.5		6
300	12	7.0	5.5	5.5	8.5		7.0		5
350	14		5.4	5.5	-				4
400	16		4.5	5.0	8.5 (14")				4
450	18			5.0	7.0 (16")				
500	20			5.5					
600	24			5.0					
650	26			6.0					
700	28			6.0					
750	30			5.5					
800	32			-					
900	36			4.5					

1) Seat supported 2) Trunnion 3) S/G seat

Table 5 Shift caused by dead angle, mm/inch

α_0	Segment C	Segment E	Segment D
20°	*)	6.1/0.24	8.1/0.31
19°	*)	5.8/0.22	7.7/0.30
18°	*)	5.5/0.21	7.3/0.28
17°	*)	5.2/0.20	6.9/0.27
16°	*)	4.9/0.19	6.5/0.25
15°	3.1/0.12	4.6/0.18	6.1/0.24
14°	2.9/0.11	4.3/0.16	5.7/0.22
13°	2.7/0.10	4.0/0.15	5.3/0.20
12°	2.5/0.09	3.7/0.14	4.9/0.19
11°	2.3/0.09	3.4/0.13	4.5/0.17
10°	2.1/0.08	3.1/0.12	4.1/0.16
9°	1.9/0.07	2.8/0.11	3.7/0.14
8°	1.7/0.06	2.5/0.09	3.3/0.12
7°	1.5/0.05	2.2/0.08	2.9/0.11
6°	1.3/0.05	1.9/0.07	2.5/0.09
5°	1.1/0.04	1.6/0.06	2.1/0.08
4°	0.9/0.03	1.3/0.05	1.7/0.06

*) Segment C: α_0 max. 15°

- Set the input signal at the closed limit of the valve so that it is 2 % i.e. 0.3 mA higher or lower than the limit value, (e.g. $4 + 0.3 = 4.3$ mA or $20 - 0.3 = 19.7$ mA). Turn the zero adjustment nut (61) with a screwdriver or fingers so that the actuator comes slowly to the closed limit. The valve should open slightly with a 4 % change in signal, that is 0.6 mA, (e.g. $4 + 0.6 = 4.6$ mA or $20 - 0.6 = 19.4$ mA). See Figure 13.
- Set the input signal to the other limit value. The valve should be entirely open at 100 %, i.e. 20 mA or at 0 %, i.e. 4 mA. The valve should start to operate to closed direction at 98 %, i.e. 19.7 mA or 4.3 mA.
The range (turning angle) increases by turning the range adjustment potentiometer (35.6) counterclockwise and decreases by turning clockwise.
- The zero and range adjustments affect each other, so stages 4 and 5 must be repeated a few times.
- Screw on the pointer (32) into place so that the yellow line is in the direction of the valve closing member. Tighten the screw (57).

7 SPLIT-RANGE ADJUSTMENT

In principle, split range adjustments are made in the same manner as for a normal signal range. Select a split range, 4–12 mA or 12–20 mA, from the cam plate. See Figure 9.

8 MAINTENANCE

CAUTION:

Do not dismantle a pressurized positioner!

NOTE:

Ensure the cleanness of the air piping.

Regular maintenance is not necessary.

The need for maintenance depends on the quality of the instrument air. See also Section 2.5.

If there is need for servicing proceed according to the following sections.

8.1 Supply air filter

The supply air filter (50) is located in the supply air connection (S); the filter can be removed for cleaning.

8.2 Pilot valve

Remove the pilot valve (44) by first loosening the nuts (49), and then by lifting off the protective plate (48), the changeover piece (46) and the gasket (45).

The pilot valve spool (44.2) should slip easily in the pilot valve body (44.1).

If the pilot valve sticks, wash the body and spool with solvent.

NOTE:

The pilot valve body and spool constitute a pair, and must not be replaced separately.

See the exploded view for the correct installation position of the pilot valve. The size code for the pilot valve on the body, for example DIA 4.0, must be visible on the right side.

Check the condition of the O-rings (43 and 47) and of the gasket (45). The end of the leaf spring on the beam must be on top of the pilot valve spool (Figure 13). Make sure that the end of the beam (5) goes into the spool groove without sideways deflections. After tightening the nuts (49), check the beam once again by hand to see that the pilot valve moves readily.

8.3 Replacement of the diaphragms

Remove the spring (40) and loosen the screws (23). Remove the zero adjustment wheel, the screw (15) and the nut (16). Replace the diaphragms (13, 14). See Fig. 16. Note the installation position of the diaphragms convolution.




Fig. 15 Replacement of diaphragms

Check during assembly that the large O-rings (11, 12) and the small ones (18, 19, 20, 21) are in place. Check the condition of the gasket (55) and secure the nut (16) with Loctite 242. Fasten the zero adjustment wheel (61). Tighten the cover screws (23) evenly. Check the positioner adjustment after replacing of diaphragm.

Note: O-rings (11, 12) in the old construction only (manufactured before 12/94).

8.4 Force coil-nozzle assembly

Repairing of the force coil-nozzle assembly requires good knowledge, workmanship and special tools.

It is highly recommended to replace a faulty assembly with a new one. Handle and disassemble the coil-nozzle assembly in the cleanest and most dust-free surroundings possible.

Removing the force coil-nozzle assembly

1. Disconnect the signal wires from the terminal.
2. Remove the springs (40, 41) and loosen the terminal screws (36). Remove the terminal card (35).
3. Hold on to the assembly and loosen the screws (38) in the back wall of the case.

Cleaning the magnet air gap

1. Remove the fastening screw (169) of the magnet (168) and lift the magnet carefully out of the body. Clean the magnet air gap with e.g. tape.
2. Place the magnet into the body carefully, making certain that the moving force coil does not jam in the air gap. Tighten the screw (169) firmly.

Mounting the force coil-nozzle assembly

Check the O-ring (39) in the case and the location of the wire in the body groove. Turn the screws (38) until tight. Mount the terminal card and the springs. Note the correct position of the spring (40), see Section 4.3. Check the adjustment.

8.5 Changing the restriction assembly

Loosen the screw (25) to remove the restriction assembly (24). A blocked restriction and/or filter can be cleaned if needed. Replacing the whole assembly is although recommended.




Fig. 16 Restriction assembly (24)

9 TROUBLESHOOTING

9.1 Electrical defects

1. The electrical condition of the positioner can be measured in the field in line without shutting down the apparatus. There are measurement terminals, see Figs. 7 and 8, for voltage (U) and current (I) on the terminal card. Pull out the jumper before taking the measurement. Note the correct polarity of the meter.
2. Current and voltage measurements can be used to determine whether the signal line and the electrical components of the positioner are in order.

Table 6 Current and voltage measurements

Measurement		Possible faults
U (V)	I (A)	
0	(—)	Signal wire polarity wrong
No	No	Signal wire defect. Wire not connected to terminal
>4	When I=20 mA	Coil connection wire or coil winding defect. Shunt resistance defective
0	Yes	Coil or shunt resistance short circuited

9.2 Mechanical defects

1. A change in the input signal does not affect the position of the actuator.
 - supply pressure too low
 - diaphragms damaged
 - pilot valve sticks
 - seals in the changeover piece leak
 - tubes between the positioner and the actuator, change-over piece or position of the cam wrong, see Fig. 6
 - actuator and/or valve jammed
 - restriction assembly blocked, see Fig. 17
2. The actuator goes to the final position with a small change input signal.
 - tubes between the positioner and the actuator, the changeover piece or the position of the cam wrong.
3. Inaccurate positioning
 - pilot valve dirty
 - beam (5) pushes the pilot valve spool sideways
 - diaphragms damaged
 - dirt in the magnet air gap
 - actuator torque too low
 - supply pressure too low
 - valve torque requirement increased
4. Overshooting or too slow
 - positioning setting for the internal feed-back spring wrong
 - pilot valve dirty or of the wrong size, see Table 2
 - supply air tube too small or supply air filter dirty
 - valve sticks
5. Zero point unstable
 - restriction assembly dirty
 - inaccurate dead angle α_0 adjustment

10 OPTIONS

10.1 NE700/R dust-proof construction (IP65)

For extremely dusty environments. The protective cover (3) behind the standard positioner is replaced with an exhaust port with a 3/4 NPT filter. Please note: do not remove the exhaust port.

10.2 NE700/A with pressure gauges

The positioner (manufactured after 9/92) can be equipped with a pressure gauge block. The block (70) is attached with three self-tapping screws (72). The O-rings (71, 3 pcs.) must be in position before mounting. Check tightness after mounting.

For all other constructions see Type code, Chapter 14.

11 TOOLS

In addition to standard general tools, you need the following equipment:

- calibration device for adjustments
- multimeter

12 ORDERING SPARE PARTS


When ordering spare parts, always include the following information:

- type code, sales order number, serial number
- number of the parts list, part number, name of the part and quantity required

This information can be found from the identification plate or documents.

13 DRAWINGS AND PARTS LISTS

13.1 Exploded view and parts list




Item	Qty	Description	Spare part category	Item	Qty	Description	Spare part category
1	1	Housing assembly		42	1	Spring	
2	1	Cover assembly	2	43	1	O-ring	1
3	1	Protective cover		44	1	Pilot valve assembly	2
	1	Exhaust port (NE700/_G)		45	1	Gasket	1
4	1	Screw		46	1	Changeover piece	
5	1	Beam assembly		47	2	O-ring	1
6	1	Plate		48	1	Protective plate	
7	2	Screw		49	2	Hexagon nut	
8	1	Lower diaphragm plate	1	50	1	Filter	
9	1	Middle diaphragm plate	1	53	3	Connector	
10	1	Upper diaphragm plate		54	1	Adapter	
13	1	Diaphragm	1	55	1	Gasket	1
14	1	Diaphragm	1	57	1	Grub screw	
15	1	Screw		58	1	Upper support plate	
16	1	Hexagon nut		59	2	Barrel nut	
17	1	Diaphragm housing assembly		61	1	Zero adjustment nut	
18	1	O-ring	1	62	1	Hexagon socket plug	
19	1	O-ring	1	64	1	Body	
20	1	O-ring	1	65	1	Lock ring	
21	1	O-ring	1	68	2	Spring	
22	1	Diaphragm cover		69	2	Guide	
23	1	Screw		70	1	Pressure gauge block	
24	1	Restriction assembly	1	71	3	O-ring	
25	1	Screw		72	3	Screw	
26	1	Shaft assembly	3	73	1	Pressure gauge	
27	1	Washer		74	2 (1)	Pressure gauge	
28	1	O-ring	1	76	1	Double fitting	
29	1	Cam plate		77	1	Filter regulator	
30	1	Locking wheel		78	1	Reduction fitting	
31	1	Screw		79	1	Pressure gauge	
32	1	Pointer		98	2	Screw	
33	1	Lever arm assembly		99	2	Spring plate	
34	1	Retaining ring	1	100	1	Additional plate	
35	1	Terminal card assembly	3	101	2	O-ring	
36	2	Screw		102	1	Plug	
37	1	Force coil-nozzle assembly	3	105	1	ID plate	
38	2	Screw		109	1	Seal	
39	1	O-ring	1	110	4	Screw	
40	1	Spring	1	*) Only in positioners manufactured before 12/94			
41	1	Spring	1				

Spare part category 1: Parts for basic maintenance. Delivered as a set

Spare part category 2: Parts for spool valve and cover replacement.


Spare part category 3: Parts for shaft and force coil-nozzle replacement.

13.2 Mounting parts for B1C6-502 and B1J8-322 actuators (S1)



Item	Qty	Description
1	1	Mounting bracket
2	1	Draught piece
3	4	Washer
4	4	Screw
28	4	Screw
29	2	Screw
36	1	Coupling jacket

13.3 Mounting parts for Quadra-Powr® actuators (S1)




Drive: male

Item	Qty	Description
1	1	Mounting bracket
2	2	Coupling half
3	1	Adapter
4	4	Screw
5	4	Hex nut
6	1	Screw
7	4	Screw
8	4	Washer
9	4	Screw
10	4	Washer

Drive: female spline


Item	Qty	Description
1	1	Mounting bracket
2	1	Ear
4	4	Screw
28	4	Screw
29	1	Screw
30	(4)	Screw
35	1	Coupling
36	1	Coupling jacket

13.4 Mounting parts for B1C6-20 and B1J8-20 actuators (S2)



Item	Qty	Description
1	1	Mounting bracket
2	1	Draught piece
3	2	Washer
4	2	Screw
5	1	Bracket
6	1	Washer
7	1	Screw
8	2	Washer
10	1	Rod
11	2	Bushing
12	2	Screw
13	2	Stud (B1C6 only)
14	2	Hexagon nut (B1C6 only)
26	2	Locking nut
27	2	Washer
28	2	Screw

13.5 Mounting parts for B1C25-502 and B1J25-322 actuators (S2)



Item	Qty	Description
1	1	Mounting bracket
2	1	Draught piece
3	2 (4)	Washer
4	2 (4)	Screw
8	2	Washer
9	2	Screw
10	1	Rod
11	2	Bushing
12	2	Screw
26	2	Locking nut
27	2	Washer
28	2	Screw

14 TYPE CODE

ELECTRO-PNEUMATIC POSITIONER NE 700

1.	2.	3.	4.	5.	6.		
NE	7	2	6		/	S1	K

1.	PRODUCT GROUP
NE	Electro-pneumatic positioner

2.	SERIES CODE
----	-------------

3.	INPUT SIGNAL RANGE
2	4-20 mA; 0-20 mA

4.	PILOT VALVE SIZE	CONNECTIONS S, C1, C2
4	Ø4 mm	1/4 NPT
6	Ø6 mm	1/4 NPT
7	Ø6 mm HC	3/8 NPT

5.	ACTION
	Suitable for Double and Single action, without sign.
A	Single action, linear motion. Applicable ONLY to D/R series spring diaphragm linear actuators, max. stroke size 57 mm (2-1/4 in).

6.	OPTIONS
	If several options below are needed to the same positioner, the codes shall be marked in presented order from top. Temperature range for various options shall be considered carefully.
-	Standard, IP 54 enclosure, PG11 conduit entry. S1 always to be defined. Temperature range -25° to +85 °C / -13° to +185 °F.
R	Water and dustproof enclosure IP65 / NEMA 4 and 4X.
W	Better vibration resistance. Special flexure pivot and diamond coated pilot.
H	High temperature construction. Viton diaphragms and seals. Temperature range -10° to +120 °C / +14° to +248 °F. Not available with options A and accessory K.
S1	Positioner with attachment face acc. to standard VDI/VDE 3845, equipped with an H-clip. When the units are separate deliveries, VDI/VDE ear is supplied. Not applicable to globe valve actuators (5th sign A).
J30	Square shaft and special mounting kit. Available in US only.
A	Pressure gauges, scale bar/psi/kPa, basic material brass, nickel plated, housing stainless steel, glycerine filled. 5th sign always to be defined. Temperature range -25° to +70 °C / -13° to +158 °F.
Y	Special construction.

-□	ACCESSORIES
K	Filter regulator for supply air type BELLOFRAM 51FR. Pressure gauge, scale bar/psi/kPa, basic material brass, nickel plated, housing stainless steel, glycerine filled. Temperature range -18 °C - +52 °C / -10 °F - +125 °F. Filter size 5 µm. Not available with HC-pilot (4th sign 7) Specified in the option sticker. In connection with the Ø6 HC-pilot valve (4th sign 7), must be used large capacity filter regulator (not K) for actuator bigger than B1C 40 and B1J 32. Installation with mounting bracket.
CE01	PG11 / 1/2 NPT conduit entry nipple. Will be specified in the option sticker.
CE02	PG11 / M20x1.5 conduit entry nipple. Will be specified in the option sticker.
CE03	PG11 / R1/2 (PF1/2) conduit entry nipple. Will be specified in the option sticker.

Subject to change without prior notice.

Neles, Neles Easyflow, Jamesbury, Stonel, Valvcon and Flowrox, and certain other trademarks, are either registered trademarks or trademarks of Valmet Oyj or its subsidiaries in the United States and/or in other countries.

For more information www.neles.com/trademarks

Valmet Flow Control Oy

Vanha Porvoontie 229, 01380 Vantaa, Finland.

Tel. +358 10 417 5000.

www.valmet.com/flowcontrol

