




Features

- Compact size
- · Lightweight unit
- · High accuracy for precision control
- Polymer construction for corrosive resistance
- · Non-rising adjustment knob
- · Manifold mount capability
- · Push to connect fittings in all ports
- Separate control chamber isolates the Diaphragm from the main flow to eliminate hunting and buzzing

Operating Principles

Downstream pressure is transmitted through the Aspirator Tube to the bottom of the Diaphragm Assembly. As long as the pressure acting on the bottom of the Diaphragm Assembly produces a force less than the spring force acting on the top of the Diaphragm Assembly, the Relief Valve remains closed. When system pressure increases, the force on the bottom of the Diaphragm Assembly increases beyond the set point. When system pressure increases beyond the set point, the assembly moves upward, lifting the Relief Valve from its seat and vents the downstream air.

If downstream pressure decreases below the set point, the assembly moves downward closing the Relief Valve.



Specifications

Flow Capacity

10 SCFM (17.0 m³/HR) @ 120 psig, [8 BAR], (800 kPa) system pressure

Maximum System Pressure

150 psig, [10 BAR], (1000 kPa)

Sensitivity

5" (12.7cm) Water Column

Ambient Temperature

0°F to +160°F, (-17.8°C to 71.1°C)

Materials of Construction

Body and Housing	Glass Filled Acetal
Valve	
Diaphragm	Polymer Reinforced Nitrile

Catalog Information

