


2.2kW ~ 1.5MW / 230 ~ 690V

# SOFTSTARTER SS7

High Performance, High Function System Drive




### Optimized Solution for high performance drive

**2.2kW - 1.5MW / 230 - 690V**



#### Optimized motor control solution



##### Slow Speed

SS7 Series allows torque adjustment at slow speed, thus it will adapt to any type of load requirement. this setting is ideal for machine positioning, as ceramic mills, etc.

##### Dynamic Torque Control

SS7 Series are featured with Dynamic Torque Control, exclusive starting method, it means progressive soft starting in those high inertia applications. With this control algorithm, progressive acceleration and optimization of starting current peak is achieved.

##### D.C. Brake

In some applications the deceleration ramp is not enough. DC Injection setting is provided in SS7 Series for those, specially in high load inertia machines.

##### Pump Control

An special designed control algorithm for decelerating pumps is provided in SS7 Series. This special adjustment does not operate in function of lineal stop curve for quadratic torque loads, as it is normally operated, but automatically it will adapt to hydraulic system curve.

##### Serial Communications

SS7 is available with in-built RS232/485 serial ports, developed for integration into the most commonly used industrial communication protocols. While MODBUS protocol is standard, other protocols are supported including PROFIBUS-DP, DeviceNet.



### External or Built in Bypass

SS7 softstarter offers both possibilities. The user can choose the standard model offering the possibility of installing an external contactor for bridging the power stage once acceleration ramp is finished, until the start of deceleration ramp. Otherwise the user can choose the new SS7 model with built in bypass which will offer the same functionality without requiring any external device installation. In any case, SS7 control stage remains monitoring all control operations and motor protections.

### Permanent Information

SS7 Series displays constantly, motor status and complete information of the installation where it is integrated.

The user will access locally (keypad unit) or remote (serial communications) to the following information :

- Voltage in each phase
- Total and partial
- Motor phi cosine (Power Factor)
- Motor shaft torque
- Power (kW) and current (I) in each phase
- Fault history (5 most recent faults)
- Number of starts
- Analogue input / output status
- Digital input /output status
- Timer, total and partial

### Integration and Control

SS7 Series make easy its integration into any automation process.

Via 2 analogue inputs 0-10V and 4-20mA, 5 configurable digital inputs, 1 PTC input, 1 analogue output 4-20mA and 3 changeover configurable relays.

### Full Protections

All protections included in SS7 Series are translated to a better control and motor security.

- Input phase loss
- Rotor locked
- Phase imbalance > 40%
- High input voltage
- Low input voltage
- Motor overload
- Motor underload
- Motor overtemperature PTC
- Shearpin current
- Input phase sequence

### Multivoltage

Only one softstarter for 230V/400V/440V and 500V, simply adjusting SS7 current to motor's.


For 690V, please consult tables available at standard ratings section.

### International Standards

SS7 complies with international standards as CE, cTick, UL and cUL



### Display Unit + Keypad Control



Indicating LEDs

LED Display

Control Keypad


- ON Indicate power in the control board.
- RUN Flashing : Accelerating / Decelerating.  
Lighting : The motor is running at mominal speed.
- FAULT The SS7 has tripped on fault protection.

- Status Line (Top)  
Control Line (Bottom)

- \* To unfold the screen groups.
- To scroll between screen groups.
- + To scroll between screen groups.
- START Motor Start.
- STOP RESET Motor Stop / Reset.

## &gt;&gt; Standard


## Configuration of Control Wiring



## &gt;&gt; Bypass built in


## Configuration of Control Wiring

## FACTORY SETTINGS




(1) Reserved for internal Bypass activation

## Configuration of Power Wiring



## Configuration of Power Wiring



## >>> Technical Specifications

Input	Input voltage	3 Phase, 230-500V, 690V [-20%~+15%]
	Supply frequency	47-62Hz
	Control voltage	220-230V ( $\pm 10\%$ )
Output	Output voltage	0-100% Supply voltage
	Output frequency	47-62Hz
	Efficiency (at full load)	> 99%
Environmental Conditions	Ambient temperature	-10°C ~ +45 °C
	Altitude losses	Below 3,000m <sup>*note 1</sup>
	Ambient humidity	Less 95% (non-condensing)
	Enclosure	IP20
Serial Communications	Standard	RS232/485, Modbus
	Option	Profibus, DeviceNet
Motor Protections		Input phase missing, High current, Low input voltage, Starting current limit, Rotor locked, Motor overload (thermal model), Underload, Phase unbalance, Motor overtemperature (PTC, normal status 150R-2k7), Shearpin current
Protections		Thyristor fault, SS7 over temperature
Sources Control		Local via keypad, Remote via digital inputs, Remote via Serial Communications (Modbus, RS232/485)

\*note 1) More 1,000m, 1% derating each 100m

Adjustments	Torque surge, Initial torque, Initial torque time, Acceleration time, Current limit : 1-In, Overload : 0.8-1.2 In, Overload slope : 0-10, Deceleration time / Freewheel stop, DC braking, Slow Speed (1/7 fundamental frequency), Dual setting Number of starts allowed, Torque control, Water hammer surge control stop
Input Signals	2 analogue inputs, 0-20mA or 4-20mA, 0-10V 5 configurable digital inputs (Start, Stop, Reset, DC break, etc..) 1 PTC input
Output Signals	1 analogue output 0-20mA or 4-20mA 3 changeover output relays (250VAC, 10A non inductive)
Display Information	Phase current, Supply voltage, Relays status, Digital inputs / PTC status, Analogue inputs value, Analogue output value, Overload status, Motor supply frequency, Motor power factor, Developed power, Motor shaft torque, Fault history (5 most recent faults)
LED's Indications	LED1 (green) : Voltage present on control board LED2 (orange) : Blinking, Motor accelerating / decelerating On, motor running LED3 (red) : Fault present

\*note 2) For additional information consult the technical manual

## >>> Softstarter applications

According to this information, there are two utilisation categories for the Electronics Softstarter, described as follow :

- 1) Starting Time
- 2) Starting Current
- 3) Ambient Temperature
- 4) Time at OFF status
- 5) Number of Startings per Hour

### EXAMPLE

1 90 : 2 AC53b

3 4.5 - 4 30 : 5 330

- ① Rated Current of the Softstarter under the described conditions : In, (90 Amps)  
 ② The thyristors will be bypassed  
 ③ Starting Current, as multiple of the nominal current (In), that means :  $4.5 \times In$

- ④ Starting Time, in seconds, (30s)  
 ⑤ Seconds between the end of starting and the beginning of next starting (10 startings per hour)

## >>> Common Applications

Example : The application is: Fan(fresh Air), 400V, 55kW motor

Look at 400VAC table right column (AC53b 4.5-30:330) 55kW means the softstarter coded SS7011B with nominal current of 110A

COMMON APPLICATIONS	CHARACTERISTIC STARTING CURRENT
<b>WATER AND WASTEWATER</b>	
Centrifugal Pumps	$3.0 \times In$
Mono and High Pressure Pumps	$4.0 \times In$
Multistage Pumps	$4.0 \times In$
Vertical Pumps	$3.0 \times In$
Split Chamber Pumps	$3.5 \times In$
Submersible Pumps	$3.5 \times In$
<b>VENTILATION</b>	
Fans (extraction)	$3.5 \times In$
Fans (fresh air)	$4.5 \times In$
Condensor Fans	$3.5 \times In$
Climatization Turbine	$4.5 \times In$
<b>PULP AND PAPER INDUSTRY</b>	
Refine Pumps	$4.0 \times In$
Pulp Pumps	$4.0 \times In$
Vacuum Pumps	$4.0 \times In$
Pulp Machines	$4.5 \times In$
Trommels	$4.0 \times In$
Pulp Mixers	$4.0 \times In$
Filters	$4.0 \times In$
<b>METALS, AGGREGATES AND MINERALS</b>	
Dust Filters Fans	$3.5 \times In$
Conveyor Belts	$4.5 \times In$
Crushers	$3.0 \times In$
Hammer Mills	$4.5 \times In$

COMMON APPLICATIONS	CHARACTERISTIC STARTING CURRENT
<b>FOOD INDUSTRY</b>	
Air Compressors	$4.0 \times In$
Sorters	$3.5 \times In$
Bottle Wash Machines	$3.0 \times In$
Driers	$4.5 \times In$
Centrifuges	$4.0 \times In$
Crushers, Punchers	$4.5 \times In$
Palletizers	$4.5 \times In$
Separators	$4.5 \times In$
Cutters	$3.0 \times In$
Material Handling	$3.5 \times In$
<b>TOOLING MACHINES</b>	
Arm Saws	$4.5 \times In$
Buzz Saws	$3.5 \times In$
Stamping presses	$4.5 \times In$
Crumbing Machines	$3.5 \times In$


COMMON APPLICATIONS	CHARACTERISTIC STARTING CURRENT
<b>PETRO-CHEMICAL</b>	
Centrifugal Machines	$4.0 \times In$
Screw Pumps	$4.0 \times In$
Gas Pumps (Propane, butane)	$3.0 \times In$
Crude Oil Extraction Pumps	$4.5 \times In$
Crude Oil Transfer Pumps	$4.5 \times In$
Hydrocarbon Transfer Pumps (liquid Stage)	$3.5 \times In$
Transport and Packaging	$3.5 \times In$
Conveyors	$3.5 \times In$
<b>GENERAL</b>	
Hydraulic Equipment	$3.5 \times In$
Agitators	$4.0 \times In$
Compressors (Screw compressor, without load)	$3.0 \times In$
Compressors (Reciprocating compressor, without load)	$4.0 \times In$
Conveyors	$4.0 \times In$
Mixers	$4.5 \times In$






## Dimensions


Frame 1




Frame 2




Frame 3



Frame 4



Frame 5



Frame	Code	Dimensions (mm)			Weight (kg)
		H	W	D	
1	SS7009 - SS70090	414	226	230	11.6
	SS7009.6 - SS70090.6				12.1
	SS7009B - SS70090B				
	SS7009.6B - SS70090.6B				
2	SS70110 - SS70250	523	314	260	19
	SS70110.6 - SS70250.6				21
	SS70110B - SS70250B				
	SS70110.6B - SS70250.6B				
3	SS70275 - SS70460	791	580	309	53.6
	SS70275.6 - SS70460.6				60.6
	SS70275B - SS70460B				
	SS70275.6B - SS70460.6B				
4	SS70580 - SS71000	926	640	324	77.6
	SS70580.6 - SS71000.6				86.6
	SS70580B - SS71000B				
	SS70580.6B - SS71000.6B				
5	SS71200 - SS71500	1552	1084	475	300
	SS71200.6 - SS71500.6				

## Green Innovators of Innovation



### Safety Instructions

- For your safety, please read user's manual thoroughly before operating.
- Contact the nearest authorized service facility for examination, repair, or adjustment.
- Please contact qualified service technician when you need maintenance.  
Do not disassemble or repair by yourself !
- Any maintenance and inspection shall be performed by the personnel having expertise concerned.

## LS IS Co., Ltd.

©2010.05 LS Industrial Systems Co., Ltd. All Rights Reserved.

### ■ HEAD OFFICE

LS-ro 127(Hogye-dong), Dongan-gu, Anyang-si,  
Gyeonggi-do 431-848, Korea

- Middle East +82-2-2034-4901 / bonseongk@lsis.biz
- Europe & Africa +82-2-2034-4376 / ywsohn@lsis.biz
- Asia Pacific +82-2-2034-4645 / sungkyup@lsis.biz

### ■ Global Network

#### • LSIS Europe B.V. » Amsterdam, Netherland

Address: 1st Floor, Tupolevlaan 48, 1119NZ Schiphol-Rijk, The Netherlands  
Tel: 31-20-654-1420 Fax: 31-20-654-1429 e-mail: junsrickp@lsis.biz

#### • LSIS (Middle East) FZE » Dubai, U.A.E.

Address: LOB 19 JAFZA VIEW TOWER Rm 205 Jebel Ali Freezone, P.O.BOX 114216, Dubai, U.A.E.  
Tel: 971-4-886 5360 Fax: 971-4-886-5361 e-mail: jungyongl@lsis.biz

#### • Dalian LSIS Co., Ltd. » Dalian, China

Address: No.15, Liaohexi 3-Road, Economic and Technical Development zone, Dalian 116600, China  
Tel: 86-411-8273-7777 Fax: 86-411-8730-7560 e-mail: lxxk@lsis.com.cn

#### • LSIS (Wuxi) Co., Ltd. » Wuxi, China

Address: 102-A , National High & New Tech Industrial Development Area, Wuxi, Jiangsu,214028, P.R.China  
Tel: 86-510-8534-6666 Fax: 86-510-522-4078 e-mail: xuhg@lsis.com.cn

#### • LS-VINA IS Co., Ltd. » Hanoi, Vietnam

Address: Nguyen Khe - Dong Anh - Ha Noi - Viet Nam  
Tel: 84-4-882-0222 Fax: 84-4-882-0220 e-mail: srjo@lsisvina.com

#### • LS-VINA IS Co., Ltd. » Hochiminh , Vietnam

Address: 41 Nguyen Thi Minh Khai Str. Yoco Bldg 4th Floor, Hochiminh City, Vietnam  
Tel: 84-8-3822-7941 Fax: 84-8-3822-7942 e-mail: spark@lsisvina.com

#### • LSIS Tokyo Office » Tokyo, Japan

Address: 16FL, Higashi-Kan, Akasaka Twin Tower 17-22, 2-chome, Akasaka, Minato-ku Tokyo 107-8470, Japan  
Tel: 81-3-3582-9128 Fax: 81-3-3582-2667 e-mail: jchuna@lsis.biz

#### • LSIS Shanghai Office » Shanghai, China

Address: Room E-G, 12th Floor Huamin Empire Plaza, No.726, West Yan'an Road Shanghai 200050, P.R. China  
Tel: 86-21-5237-9977 (609) Fax: 89-21-5237-7191 e-mail: jinhk@lsis.com.cn

#### • LSIS Beijing Office » Beijing, China

Address: B-Tower 17FL,Beijing Global Trade Center B/D. No.36, BeiSanHuanDong-Lu, DongCheng-District, Beijing 100013, P.R. China  
Tel: 86-10-5825-6025,7 Fax: 86-10-5825-6026 e-mail: cuixiaorong@lsis.com.cn

#### • LSIS Guangzhou Office » Guangzhou, China

Address: Room 1403,14F,New Poly Tower,2 Zhongshan Liu Road,Guangzhou, P.R. China  
Tel: 86-20-8326-6764 Fax: 86-20-8326-6287 e-mail: linsz@lsis.biz

#### • LSIS Chengdu Office » Chengdu, China

Address: 12Floor, Guodong Building, No52 Jindun Road Chengdu, 610041, P.R. China  
Tel: 86-28-8612-9151 Fax: 86-28-8612-9236 e-mail: yangcf@lsis.com.cn

#### • LSIS Qingdao Office » Qingdao, China

Address: 7840,Haixin Guangchang Sheny Building B, No.9, Shandong Road Qingdao 26600, P.R. China  
Tel: 86-532-8501-6568 Fax: 86-532-583-3793 e-mail: lirj@lsis.com.cn

Specifications in this catalog are subject to change without notice due to continuous product development and improvement.